PROCEDURE FOR USING DIAGNOSTICS FOR MUX 310 AND LOTUS 700

- To load in MUX diagnostics, do a shutdown to filename <u>MUX 310 DP</u>. Refer to Point 4 Mighty MUX Diagnostics Manual for instructions.
- 2) To load in Lotus 700 diagnostics, do a shutdown to filename <u>DC700</u>. Refer to Point 4 Lotus 700 Disc Controller Utilities and Diagnostics Manual for instructions.

1